prosepra

Neck and Shoulder Massager

PL017

prosepra

Neck and Shoulder Massager

PL017

Operating Manual

Introduction

Prosepra's PL017 Neck and Shoulder Massager is a user-friendly product. The neck and shoulder massager brings the ultimate power of a soothing and tapping massage. It can be used on your neck, shoulders, back, thighs, and many more areas. The tapping mechanism delivers various intensity and frequency massages directly to the spots of tension in your muscles and provides instant relief. The two massage heads work sequentially. This action helps loosen tight muscles by increasing blood flow. You can use the automated program during your massage session. PL017 is a perfect personal massager for both the home and office.

Features of PL017 Neck and shoulder massager:
1. Ultimate tapping massage device
2. Two massage heads
3. Adjustable intensity and frequency
4. Perfect for the home and office

Content

Safety Warnings — 01
Set up — 02
Operating the product — 02
Trouble shooting — 03
Specifications — 03
Consumer warranty — 03
Warranty card — 04
Prosepra company contact — 04
Use positions diagrams — 05

Safety Warnings

When the Neck and shoulder massager is not in use, always unplug it from the power outlet. This action conserves energy, and prevents electric shock as well as damage to the product.

Warnings:

Please take these precautions to prevent electric shock, burns, fires, and other injuries.
1. Do not leave this product unattended when it is in use. Unplug the product from the power surge protector after usage.
2. Do not operate this product in an excessively humid environment, and avoid direct sunshine upon the product where it is set up.
3. Do not insert any sharp objects into the fabric of the product. These objects might include keys, pens, pencils, kitchen utensils, blades, knives, etc.
4. Do not use an air refresher spray where the product is set up or in use.
5. Consult your doctor prior to using the product if you have heart, skin, and other health issues.
6. This product is not intended for children. Keep close supervision if your child uses it.
7. This product is to be plugged into a surge protector to avoid damage to its mechanism and electric components.

Attention:

1. Do not let babies and young children to play with the product, remote, or cord.
2. If you feel that the massage is too strong, stop program immediately, and disconnect the product from the power surge protector.
3. Average daily usage for massage product is about 15-30 minutes. Avoid watching television when using this product, as you may be unaware of how much time has passed. Do not use it while you are asleep.
4. This product contains electric components, wires, and other elements that cannot contact excessive moisture. For instance, the bathroom, shower room, steam room, and sauna are places where this product should not be used.

Set up

Find a good location in your living room, bedroom, family room, or office to set up the Prosepra's PL017 Neck and shoulder massager. Find a permanent spot to place the product. Use a power surge protector for connecting the product.

Take the product out of the retail box, place it at your selected location, and insert the cord to the surge protector. Turn the surge protector on.

Operating the product

Function:

1. Two automatic programs
2. Two tapping heads
3. Mode I and Mode II for program selection
4. Fifteen-minute massage session.

Operating instruction:

Setup: Place the unit on your neck, shoulder, or other areas, and hold onto the two stripes tightly with your hands.

Power: Press power to start automatic program. If power is connected, the light indicator inside this button will turn on.

Tapping adjustment: Use Mode I or Mode II to select a program. Each working mode delivers tapping massage with various intensity and frequency.

After you are done massaging, press the Power button to turn it off. Unplug the cord from the power surge protector.

Recommended time of usage: 15 to 30 minutes daily

Trouble shooting

Prosepra's PL017 Neck and shoulder massager is a user friendly product. It is built to last. If you follow the operating manual, use it properly, and follow the precautions, this product will last for more than a decade.

Should the following situations happen, please take recommended trouble shooting procedures:
1. If the fabric is torn, stop using it immediately.
2. If a wire is broken or does not work, unplug the product from the surge protector. Contact Prosepra if it is under warranty.

Specifications:

Rated Voltage: ~110V
Rated Frequency: 60Hz
Max. Power: 100W
Net weight: 5.5lbs
Gross weight: 6.2lbs

Consumer Warranty

Prosepra offers a 90-day standard warranty to the massage products. Labor and parts are included during warranty period. Consumers are required to provide model number and dated proof of purchase (sales receipt) when contacting Prosepra for the warranty service.

Non-warranty service is provided on a per incident basis. The consumer will verify that the product has failed and provide information for servicing the unit. All applicable repairs, parts, shipping, handling, local tax and per incident fees will be charged for non-warranty repairs and support calls.

Warranty card

prosepra

Warranty Registration Form

Product Name: _____

Product Model: _____

Purchase Price: _____

Date of Purchase: _____

Retailer: _____

First Name:_____

Last Name: _____

Address: _____

City: _____

State:_____

Zip: _____

Phone: _____

Email: _____

Signature and date: _____

Please mail to:

Prosepra Inc.
405 Boulder Court, Suite 500
Pleasanton, CA 94566

Telephone: 925-225-0888

Fax: 925-225-0660

Email: sales@prosepra.com

Positions of usage

Neck&shoulders

Upper Back

Lower Back

Abdomen

Waist

Bottom

Legs

Arms

Thighs